

Date: <u>22 - //-23</u> Rego: <u>224XIR</u> Plant ID: <u>910</u>

Make	Terex	Model	AC100/4	
Service Type	ervice Type 250hr (Bottom)		10496	
Service Hrs.	3,750hr 3,729	KM	55,943	
Next Service	4,000hr	Due (+/- 50Hr. Reading)		

Status type: Satisfactory ✓ Action Required ✗ Not Applicable NA

Status type: Satisfactory ✓ Action Required ➤ Not Applicable NA					
Descript	ion		Status	Action/ Comments	
		250hr /	750hr Ser	vice	
	draulic Pump PTO, Mou	inting & Bolts	1		
	Check Transmission Oil Level		1		
Check Tra	nsfer Case Oil Level			Harrish Harrish Harrish	
Check Tra	nsfer Case Cooler Syst	em for Leaks			
	arder Oil Level		/		
Check ALL	Differentials Oil Levels	3	/		
	netary Reduction (s) Oi				
Check Sus	p Cylinder - Condition	Leaks / Positions			
Check ALL	Suspension componer	nts - wear / Tightness	/		
Check ALL	Drive / Jack Shaft Univ	versal Joints	1		
Check / Lu	be ALL Universal Joints	s on Drive Line	1		
Check Bral	ke Lining Thickness / W	/ear - record thickness			
	L/H	R/H		Minimum Thickness =	mm
Axle 1				80%	
Axle 2				"	
Axle 3			1	11	
Axle 4			1,	11	
	Brake Operation		1,		
Check Serv	Check Service Brake Operation		1,		
	Check all covers, panels for security		//		
Drain ALL A	Drain ALL Air Tanks of Water / Sediments		1,		
	Check Diff Lock Operation		1		
Inspect stee					
	Inspect ALL steering links		1,		
	Lube ALL axles, and steering knuckle bearing		1		
Check Steering components		1,			
	Lube suspension cylinder ends				
	Lube Slew Gear / Bearing		MA		
Check Slew Gear Level		NA			
	Lube Rope drum bearing		NA		
Lube Hookb			NA.		
Lube Main E	Boom Extension Bolts/s	liding surfaces etc	NA		



NA	
101	
1/6	
NA.	
1/2	
4	
100	Both Upper and Lower
1/1	Both Opper and Lower
1/2	
- IVI	
NA	
107	
-/-	
-/	
-/	
1	
1/	Upper & Lower Engines
	Upper & Lower Engines
	Upper & Lower Engines
/	Upper & Lower Engines
//	Upper & Lower Engines
1,	Upper & Lower Engines
1,	
1,	
1,	
11	
1	
1,	
1,	
	NA N



Check Wiper Operation	/	
Check ALL Warning Lights and Buzzers	1	
Check Exhaust Brake Operation ( where fitted )	1	
Check Rotating Light Operation	/	
Check Panel Condition	1	
Check Cabin Condition		
Check Interior Light Operation	1	
Check AM/FM Radio Operation If fitted		
Check Cabin for Water Leaks	/	
Check Door Locks & Catches for Operation	1,	
Check Seat Mounting & Operation		
Refill Windscreen Washer Water & Test Operation Upper	/	
and Lower		
Check Seat Belt Condition / Operation	1,	
Check Heater Operation	1,	
Check Air Conditioning	1,	
Check for Air Leaks ALL Points		
Check for Fuel Leaks ALL Points	1,	
Check for Oil Leaks in Engine Area	1,	
Check Tyre Pressures & Tyre Condition	1	
Carry Out FULL Function/Operate Test Drive	1	
Check Hoist Limit Switch Operation	NA	
Check all crane functions for correct operation		
Lift Test Weight if Available	NA	
Check LMI / SLI Operation / Calibration	NA	
Anti-Two Block Operational	NA	
Boom Length & Angle Indicators	NA	
Manual Boom Length & Angle Indicators	NA	
Level Indicators	1	
Operation & Safety Manuals	/,	
2 Way Radios Condition / Operation	1,	
Registration Valid & In Date		



OTHER NOTES:			
* Hard to get o	gear from	stand still.	
* Clutch woin			

Completed by:	Christian. (.	Mechanic / Fitter	22-11-23.
	Name	Position	Date
	Shelder U		23-11-23
Carried Carried Control of the Contr	Name	Position	Date