

Date: 9-2-24 Rego: XQ29ED Plant ID: 937

Make	Terex	Model	AC100/4
Service Type	250hr (Bottom)	Serial No:	10595
Service Hrs.	2,750hr 2725	KM	48823
Next Service	3,000hr	Due (+/- 50Hr. Reading)	

Status type: Satisfactory ✓ Action Required ★ Not Applicable NA

Status ty	Status type: Satisfactory Action Required Not Applicable NA						
Description			Status	Action/ Comments			
		250hr /	750hr Ser	vice			
Check Hydraulic Pump PTO, Mounting & Bolts							
	nsmission Oil Level		/				
Check Tra	nsfer Case Oil Level		/				
Check Tra	nsfer Case Cooler Syst	em for Leaks					
Check Ret	arder Oil Level	- Announce Court of the Court o					
Check ALL	Differentials Oil Levels						
Check Plan	netary Reduction (s) Oil	Level					
Check Sus	p Cylinder - Condition /	Leaks / Positions	/				
Check ALL	Suspension componer	nts - wear / Tightness	/				
Check ALL	Drive / Jack Shaft Univ	versal Joints	/		3778		
Check / Lu	be ALL Universal Joints	on Drive Line	1				
Check Bral	ke Lining Thickness / W	ear - record thickness		85%			
	L/H	R/H	,	Minimum Thickness =	mm		
Axle 1							
Axle 2							
Axle 3							
Axle 4			//				
	k Brake Operation		//				
	Check Service Brake Operation		//				
Check all covers, panels for security		/,					
	Air Tanks of Water / Sec	diments					
	Lock Operation	AMAZ 16 (2.4) (4.4)					
	ering hoses		/				
	steering links						
Lube ALL axles, and steering knuckle bearing							
Check Steering components			/,				
	Lube suspension cylinder ends						
	Lube Slew Gear / Bearing						
	v Gear Level		NA				
	drum bearing		NA				
	Lube Hookblock						
Lube Main Boom Extension Bolts/sliding surfaces etc			NA				



Lubricate slew gear open teeth	NA	
Check for correct operation and Grease Sensors on SVE	177	
Inspect Main Boom Track Rollers	NA	
Inspect Main Boom extension rope track rollers	NA	
Visually Check Slew Bolts / Gear connections	NA	
Visual check for cracks	10/3	
Check Winch Gearbox Oil Level	NA	
Check Winch Rope Condition & Lubrication	NA	
Check Winch Unit Mountings & Bolts	NA	
Check Hydraulic Tank Oil Level	17	Both Upper and Lower
Visual Inspection of ALL Boom Sect. Damage	NA	Both oppor and zower
Lube Rear Boom Pivot Bearings	NA	
Lube ALL Luff Cyl. Bearings	1/4	
Top up auto greaser (if fitted)	10/1	
Inspect ALL Sheaves on Boom Assy.	NA	
Check ALL Hydraulics for Correct Operation	141)	
Check ALL Hydraulic Cyl's for Damage/Leaks	1	
Check ALL Hydraulic Cyrs for Damage/Leaks	-/	
Check ALL Hydraulic Hoses for Damage/Leaks Check ALL 'Crane Control Levers' for Operation	1	
Check ALL Wiring for Damage & Correct Routing	/	
Check Battery Electrolyte Level	1	
Clean & Check Battery Terminals-Holding Clamp		
Check Brake Expanding Cylinders	/	
Check & Tighten Axle retaining bolts, check axle screw	-/	
conn.		
Inspect steering and radius arms, bushes and ball joints	/	
Visual Inspect Air Intake pipes & hoses	1	Upper & Lower Engines
Check Coolant & Inhibitor Level / Concentration	1	Upper & Lower Engines
Check ALL Coolant / Heater System Hoses	1	Upper & Lower Engines
Visual Inspect Radiator Screen & Cooler Cores for	1	Upper & Lower Engines
Blockage		oppor a zonor zinginos
Check Fan Operation		Upper & Lower Engines
Check Alternator & A/C Compressor Mount/Bolts	1	Upper & Lower Engines
Check Engine Drive Belts	1	Upper & Lower Engines
Check Engine, Lines & Hoses for Abrasion & Position	1	Upper & Lower Engines
Check Engine Piping for Leaks	1	Upper & Lower Engines
Visual Inspect Engine Mount(s) Condition	1	Upper & Lower Engines
Spray all chrome cylinder rods	1	opportunity and a second secon
Check batteries for electolyte/ security	-	
Check Clearance Lights	1	
Check Head Lights HI/LO	1	
Check Stop Lights	1	
Check Reverse Light(s) & Alarm	1	
Check Indicators & Audible Warning	1	
Check ALL Work Lights	1	
Check ALL Instruments for Operation/Illumination	1	
Check Low Air Warning Devices	1	
Check Horn(s)	/	
Check Form(s)		



Check Wiper Operation	1					
Check ALL Warning Lights and Buzzers	1,					
Check Exhaust Brake Operation (where fitted)	1					
Check Rotating Light Operation	1			-04		
Check Panel Condition	11					
Check Cabin Condition						
Check Interior Light Operation	//					
Check AM/FM Radio Operation If fitted	1					
Check Cabin for Water Leaks	11					
Check Door Locks & Catches for Operation	1,					
Check Seat Mounting & Operation					4= 000	
Refill Windscreen Washer Water & Test Operation Upper	/		· · · · · · · · · · · · · · · · · · ·			
and Lower						
Check Seat Belt Condition / Operation						
Check Heater Operation	/,					
Check Air Conditioning					W-88 8	
Check for Air Leaks ALL Points	1					
Check for Fuel Leaks ALL Points						
Check for Oil Leaks in Engine Area						
Check Tyre Pressures & Tyre Condition		TIPES O	rearing	even - a	etting	low
Carry Out FULL Function/Operate Test Drive		1	J		U	
Check Hoist Limit Switch Operation	NA					
Check all crane functions for correct operation	/					
Lift Test Weight if Available	NA					
Check LMI / SLI Operation / Calibration	NÃO					
Anti-Two Block Operational	NA				122 /2	
Boom Length & Angle Indicators	NA					
Manual Boom Length & Angle Indicators	NA					
Level Indicators						
Operation & Safety Manuals	1,			***************************************		
2 Way Radios Condition / Operation	/,					
Registration Valid & In Date						



OTHER NOTES:						
*Tyres	wearing	even	getting	low	< 30%	
						"
						5

Completed by:	Christian. C	Mechanic / Fitter	9-2-24 Date
	Sheldon V		9-2-24
	Name	Position	Dat